



- NOTES:**
- ALL TOLERANCES ARE $\pm 1/16"$ UNLESS OTHERWISE STATED.
 - USE FOUR TO SIX CRW SCREWS EACH CORNER TO CONNECT FRONT SIDE AND BACK SIDE IN ACCORDANCE WITH BEST COMMERCIAL PRACTICE.
 - USE 8--PENNY CRW NAILS, OR BRASS SCREWS, TO PASTEN ROOF TO SIDES.

7. END USER REF ID		8. Nomenclature or Description		9. QTY REQD		10. PART OR IDENTIFYING		11. DWG SIZE		12. CODE IDENT		13. SPECIFICATION OR MATERIAL	
LIST OF MATERIAL													
UNLESS OTHERWISE SPECIFIED: ENGINEERING MATERIALS 2 PLACES DECIMALS + 000 3 PLACES DECIMALS + 000 SEE NOTES ON P300 SHEET 1				ENGINEERING DIVISION SILVER SPRING, MD. 20910				U.S. DEPARTMENT OF COMMERCE NATIONAL OCEANIC & ATMOSPHERIC ADMINISTRATION NATIONAL WEATHER SERVICE					
				PREPARED R.E.B. 4/6/07		P300A SHELTER ASSEMBLY							
				CHECKED D.A.D. 4/11/07									
				DESIGN APPROVED									
				SIZE 11" x 17"		DATE APRIL 16, 2007		DRAWING NO. P300					
								SHEET 1 OF 2 (SEE P300A, 1 SHEET)					